

Hybrid Impingers

The safer impinger

Removes the Glassware Insert

Have you tried our new Hybrid Series Impinger?

1. Snap the Removal Tool in place.
2. Unscrew the cap.
3. Easily and safely remove the insert.

The new model allows the stack tester to use a removal tool to ***SAFELY REMOVE THE GLASSWARE INSERT.*** The design of the Hybrid Impinger uses an O-ring and a threaded cap to create a greaseless, high-vacuum seal and an inner taper to hold the glass insert steady.



Features

- Safely removes stuck impinger inserts
- Reduces broken glass
- Helps avoid cuts on hands
- #28 Ball and Socket Joints
- More reliable seal between impinger and insert

